



## SAFETY INSTRUCTIONS

- Please read the user manual carefully before using your device for the first time and keep it for future reference. Any non-compliant use of the device will release the manufacturer from all responsibility.
- This device should not be used by children.
- Do not use your device if it is not functioning properly. If it has been damaged, it must be repaired by our services.
- This device is not waterproof, and the manufacturer disclaims any responsibility for use in a humid environment.

## WARNING

- Using a depleted battery is the sole responsibility of the user, who will be solely liable for any damage(s) of any kind caused to property and/or persons.
- Any use other than that specified in this manual releases the manufacturer from liability.
- Before any use, recharge your battery.

## CUSTOMER SERVICE

- For your safety, do not use accessories or spare parts other than those provided by our brand.
- Any intervention other than cleaning by the customer must be performed by our brand.



## COMMISSIONING

The product starts automatically once the battery (CR123A) is inserted. The game settings will be the last ones used.

## GAME SETTINGS

Before getting into the details, please note that the system remembers the game options, even when the product is turned off. Therefore, you won't need to adjust your device for each game (unless you change the game settings, of course).

### SETTINGS MENU

To enter the settings menu:

- ▶ Remove the battery
- ▶ Press and hold the button
- ▶ While keeping the button pressed, insert the battery.

The LED will then start flashing rapidly until you release the button. You are now in the settings menu, where you can define the maximum game time before the player's elimination.

Please note that 5 seconds of inactivity will validate the parameter and start the game.

At this stage, the game time is reset to its minimum value (1 minute).

With each press of the button, you will increase the time by 1 minute. A visual feedback will help you keep track:

1 red flash corresponds to 1 minute  
1 green flash corresponds to 5 minutes  
If you press the button once, you will increase the time by 1 minute, making a total time of  $1 + 1 = 2$  minutes, and the device will emit 2 red flashes.

Let's take an example where the maximum game time is set to 10 minutes.

You need to add 9 minutes to the initial minute.

Therefore, you will press the button 9 times and you should receive:

2 green flashes indicating: 2 x 5 minutes

This gives a total of 10 minutes.

**CONGRATULATIONS, YOUR GAME MODULE IS NOW SET UP!**

As previously explained, each time the product is restarted, it will use the parameters you have just defined.

You can, of course, redefine them at any time by reopening the settings menu.

## ONCE THE GAME STARTS...

### PLAYER STATUS

You will hear crackling sounds from the buzzer corresponding to the level of radiation exposure. The more frequent the crackling, the closer the player is to death.

Each press of the button will cause the colored LED to indicate the player's status:

- Green = OK
- Purple = Mid-life
- Red = WARNING

### PLAYER DEATH

When the LED becomes SOLID RED and the buzzer sounds continuously, the player is considered dead due to a lethal dose of radiation.

### SOUND AND LIGHT SIGNALS

It is possible to disable the signals (sound or light) if you want to create a game variant that only uses one of the two signals.

- Disabling the LED means the player can no longer check their device for status updates.
- Disabling the buzzer means the player must constantly check the dosimeter to know their status.

INSTRUCTIONS  
DOSIMETER

**CLEANING THE DEVICE**

- The device should never be immersed in water.
- If you clean it with a damp sponge, remove all batteries and ensure the entire device is thoroughly dried before reuse.
- Be careful not to rub with the abrasive side of the sponge to avoid scratching the product.

For any questions or additional information, you can write to us at:

[Contact@MyAirsoftGame.com](mailto:Contact@MyAirsoftGame.com)

Or for better follow-up, contact us directly from your customer account on our store:

[www.MyAirsoftGame.com](http://www.MyAirsoftGame.com)

**HAVE IDEAS?**

Do you have ideas? Would you like to see them realized? Feel free to let us know!



YouView YouView YouView YouView YouView YouView YouView YouView

**My Airsoft Game**

SIRET : 823 618 798 00016

109, Chemin du Champ Pequyan  
74 370 ANNECY - FRANCE

[Contact@MyAirsoftGame.com](mailto:Contact@MyAirsoftGame.com)

+337 81 21 78 45

